

Welcome to
Whistle

Whistle 3: Quick Start Guide & Instructions

1 Get the app

Download the **Whistle 3** app on your smartphone to begin set-up.



2 Set up your Whistle

Open the Whistle 3 app on your smartphone and follow the step-by-step instructions for set up. Whistle will need to connect to a Wi-Fi network, so we recommend you set up at home.



3 Let your Whistle charge

Once the LED light on Whistle is green, you'll know that it's charged. We'll send you a notification on your phone when it's time to attach the Whistle to your pet.



Whistle care

Whistle is waterproof. We recommend rinsing and drying it regularly, especially after swimming, to keep it from rusting.

Be sure to charge Whistle regularly to keep your pet safe. Enjoy!

Attaching Whistle to your pet's collar in 3 easy steps:




A. Collar attachment



B. Collar strap


1

To attach Whistle to your pet's collar, take the collar attachment (A) and collar strap (B) and place your pet's collar in between the two, so that the attachment can latch onto either side of the collar strap.




2

Insert Whistle into the collar attachment and turn clockwise to secure in place.



3

To detach Whistle, squeeze the tab on the collar attachment (A), turn counterclockwise and lift to remove.



How to charge Whistle

Attach your Whistle to the charger by turning clockwise and securing in place. Plug the USB charging cable into a computer or wall power adapter (recommend 5V). The orange light will turn on to show the device is charging. Once complete the light will turn green.