



Instruction Manual

800 Yards Remote Dog Training Collar

Rechargeable & Waterproof & Portable Training Collar with Static Shock, Vibration, Beep, Flash & Intensity Adjustment & LCD Screen

Model Number: 161



⚠ WARNING

Do not use this product for your aggressive dog, or if your dog is prone to aggressive behavior. Aggressive dogs may cause damage to the people or things around. If you are unsure whether this product is appropriate for your dog, please consult your veterinarian or certified trainer.

CAUTION:

Risk of skin damage. Please read and follow the instructions. It is important to use the collar correctly. Too tight for wearing may cause skin damage.

*Avoid wearing the collar on the dog for more than 12 hours per day.

*If possible, reposition the collar every 1 to 2 hours.

*Check the collar to prevent excessive pressure, just follow the instruction.

*Never connect a dog rope to the collar, it will cause excessive pressure on the contact area.

*Wash the neck area of your dog and the contact area of the collar weekly with a damp cloth.

*Examine the contact area of dog daily, lest rash or sore appears.

These cautions will help to keep your pet safe and comfortable.

Packing List

- 1 X Remote
- 1 X Receiver
- 1 X Nylon Belt
- 1 X USB Charging Cable
- 1 X Charger
- 1 X Test Bulb



MAIN FEATURES

1. Easy-to-use, ergonomic transmitter.
2. Rainproof receiver for bad weather training.
3. Rechargeable collar and transmitter.
4. 4 training modes: static shock/ vibration/ beep/ flash.
5. Adjustable Intensity under static shock/vibration mode from 0 to 7 levels. If the level set 0, the mode is inhibited.
6. The remote control distance of this product is 800 yards.
7. Two-dog model allows the trainer to control two dogs from one transmitter.
8. Power saving design with automatic standby and memory function. (With memory function, if the transmitter and the receiver do not run out of power, the product can work by just turning on the transmitter and the receiver. In this case, there is no need to pair them again.)

1. LCD Screen:

The LCD Screen will display different modes of the collar and the different channels for two collar receivers as well as battery indicator.

Channel 1: Indicates the selection of the first collar receiver.

Channel 2: Indicates the selection of the second collar receiver.

2. Static Shock Button: Pressing the “Static Shock” button, the receiver will emit shock.

3. Vibration Button: Pressing the “Vibration” button, the receiver will vibrate.

4. Beep Button: Pressing the “Beep” button, the receiver will emit beep sound. How many bars (show on the screen) you set, the receiver will emit the exact times of beep.

5. Flash Button: Pressing the “Flash” button will cause the LED light on the receiver to flash red once every second.

6. Intensity Up/down Button: Selects intensity level of the vibration and static Shock.

7. Channel Button: Pressing this “1/2” button will shift channel between the first and second collar receiver.

8. Model Button: Check the different working mode.


9. Turn on/off the transmitter: Turn on the transmitter by press the “Power” button one time. Press the “Power” button one time to turn off the transmitter after 4 seconds.

10. Charging port: Insert charging cable into charging port to charge the Transmitter.

11. Turn on/off the Receiver: Turn on/off the receiver by press the “Power” button one time.

12. DV-5V hole: Insert charging cable into DC-5V port to charge the receiver.

DESCRIPTION



- ① LCD Screen
- ② Static Button
- ③ Vibration Button
- ④ Beep Button
- ⑤ Flash Button
- ⑥ Up/down Buttons
- ⑦ Channel Button
- ⑧ Mode Button
- ⑨ Power Button
- ⑩ Charging port
- ⑪ Power Button
- ⑫ DC-5V port




Operation Steps:


1. Turn on the transmitter



2. Turn on the receiver



3. Press the the "power" button once again, the red light will light up and you will hear "Beep"



4. Press the "Static Shock" button on the transmitter, and you will hear "Beep" again which means this product has been matched complete. Use the test bulb to test the shock.



Test bulb

How to use two receivers at the same time:



1. Press the "1/2" button to choose channel 1 for pairing, then follow the "Operation Steps" to pair it.



2. Press the "1/2" button to choose channel 2 for pairing, then follow the "Operation Steps" to pair it.

Notes:

1. In common, if the battery is full, the receiver can work for 10 days, and the transmitter 20 days.
2. The valid distance of the remote means the straight-line distance between the Transmitter and the Collar Receiver without obstacles in between. If there are interference signals or other disruptions, the actual remote control distance may be variable.
3. Training sessions should be kept positive and short. 10 - 15 minutes for each session is recommended.
4. Presently, this product is the most effective and safest tool for training or barking prevention. Follow the correct operational instructions and you can effectively train the pet without any problems.

Important Notice:

1. The transmitter will be changed to Standby Mode if there is no operation after 5 seconds. The receiver will be changed to Standby Mode if there is no operations for one minute. Any movements from the dog will activate the receiver.
2. Press "1/2" button for selection. Channel 1 controls the first receiver and Channel 2 controls the second receiver.
3. In working mode, if you want to reconnect the receiver to the transmitter, simply press the "Power" button, there will be a beep sound indicating that it is ready to be matched.
4. The design of the receiver is rainproof. The rubber cover has to be put in the right position to ensure rainproof effect.
5. Test static shock function:
 - 1) Place the test bulb to the metal screws (ensure the metal points are attached when test the shock function).
 - 2) Press the "Static Shock" button, and the LED light will flash on.

HOW TO USE

Note: Please charge before using the product!

1.Charge the remote transmitter:

- 1) Connect the charger cable to the charging port.
- 2) Plug the charger into a standard outlet.
- 3)The icon of battery will flash.
- 4) Charge the transmitter for about one hour for the first charge or until the icon of battery stops flashing.

2.Charge the collar receiver:

- 1) Connect the charger cable to the DC-5V port.
- 2) Plug the charger into a standard wall outlet.
- 3) The red light will flash on the receiver
(If not or green light ,please plug the charger again).
- 4) Charge the receiver for about one hour for the first charge or until the light indicates charging is completed.

3.Connect transmitter and receiver

- 1) Turn on the transmitter.
- 2) Press "1/2" button to choose channel 1 for pairing.
- 3)Turn on the receiver
- 4)Press the "Power"button on the receiver again.
- 5) After a beep from the receiver, press the "Vibration button" within 30 seconds for pairing.
- 6) The collar receiver will beep if connected successfully.
- 7)If the pairing were not successful, please repeat the 3-5 steps.
- 8) To encode the second receiver, press the "1/2"button and select for the second receiver and follow the same procedure.

Frequently Asked Questions

Q:How old does my pet have to be before using Training Collar?

A:Your pet should be able to recognize basic obedience commands such as “Sit” or “Stay” This product may be too large for pets under 8 pounds.

Q: Why the remote control and the receiver can not be charged?

A:Please use the charger configured for the product. It is prohibited to use mobile phone chargers to charge the product.

Q:Can I use Training Collar with more than one pet?

A:Yes,you can simply add one more receiver collar to the system.

Q:Will I get exactly 800 yards of range with the Remote Trainer?

A:The effective range of the Remote Trainer means the straight-line distance between Remote Transmitter and Receiver Collar without obstacles in between.Range may be variable according to terrain,weather,vegetation,battery capability as well as the transmission from other radio devices.

Q:How long can I continuously deliver vibration or static shock to my pet?

A:The maximum amount of time you can press the vibration or static shock to your pet continuously is 10 seconds.After this,the vibration or static shock will stop, and the button must be released and pressed again.

Q:What do I do if my pet's neck becomes red and irritated?

A:Discontinue to use the product for a few days.If the condition persists beyond 48 hours,consult your veterinarian for help. Once the skin recovers, check the skin condition of your pet frequently.

Q:How long is the lifetime of the lithium battery ?

A:Our Lithium battery can charge 2000 times for Remote Controller and Receiver Collar.

Q:How long can I remove the Receiver Collar from my dog?

A:The Collar is not designed to be worn constantly.We recommend the Collar not be worn for more than 12 hour of every 24-hour period.

Q:How long should I process my training session for my pet?

A:Training sessions should be kept positive and short ,it is better for about 10-15 minutes each time.

Q:What kind of dogs are your training collar suitable for?

A:The collar is adjustable from length 5.9"(15cm)to 19.6"(50cm),if your pet's neck is smaller than 5.9",you have to rethread it,if your pet's neck is larger than 22",please don't buy it and this collar is not suitable for the dogs less than 8 pounds either.

Common size of different dogs

Size	Neck	Chest Measurement(cm)	Back Length(cm)	Type
Mini	20-22	25-30	19	Chihuahua, Yorkshire Terrier
Small	20-24	29-36	23	Chihuahua, Yorkshire Terrier, Poodle, Pomeranian
Medium	23-28	35-42	28	Maltese Dog, Shih Tzu
Large	27-31	41-47	31	Miniature Schnauzer, Pekingese
Large	30-34	46-53	35	Schnauzer, English Cocker Spaniel
Large	33-37	52-59	40	Beagle
Huge	43-48	76-84	60	Husky

General Training Tips

The following tips will show you how to get the best performance out of your Dog Training Collar.

- (1) Make training sessions short and positive (about 10-15 minutes for each session.) This will enable the dog to focus on the trainer.
- (2) Training one dog each time is recommended.

- 3) During the first initial training sessions, keep the dog in a familiar outdoor environment. Training in a place that the dog is not familiar with may make the dog become distracted.
- (4) Use a long leash fastened to a non-metallic collar to help the dog to learn. Ensure that the additional collar and leash does not interfere with the Contact Points of the Collar Receiver. Do not use the remote training collar without a long leash unless your dog is fully trained.
- (5) More success will occur by teaching the dog a command first before trying to reinforce the command with the Remote Transmitter.
- (6) For basic obedience training, vibration is more useful.
- (7) Issue one obedience command each time, this will reduce confusion and allow the dog to remain focused. Do not use the training system for commands that the dog has not learned.
- (8) During training, look for all the positive changes in the dog's behavior and remember to encourage it promptly with ample praise and reward.
- (9) Avoid over-correcting your dog. Use as little remote correction as possible during the training process.
- (10) When the dog has become apparently perplexed, shift the focus of the training by drawing the dog's attention to a command they have been familiar with. Example: Tell the dog to sit and give abundant praise and encouragement on successful completion of the sit command.
- (11) Do not use the training system to correct or eliminate aggressive or biting behavior. When the dog is showing signs of aggressive behavior, contact a professional dog trainer in your local area immediately.
- (12) Please keep in mind that training sessions should be kept short. Stop Training and play with the dog when the dog has made progress.