

pawple

7L AUTOMATIC PET FEEDER



USER GUIDE

PAWAUFD



7L AUTOMATIC PET FEEDER

USER GUIDE

PAWAUFD



Thank you for purchasing the Pawple™ 7L Automatic Pet Feeder. This User Guide is intended to provide you with guidelines to ensure that operation of this product is safe and does not pose risk to the user. Any use that does not conform to the guidelines described in this User Guide may void the limited warranty.

Please read all directions before using the product and retain this guide for reference. This product is intended for household use only. It is not intended for commercial use.

This product is covered by a limited one-year warranty. Coverage is subject to limits and exclusions. See warranty for details.


NOTE: Please read and review all safety precautions on page 6 before using this product.

Package Contents


- Main body
- Food bowl
- Small portion dispenser
- Large portion dispenser (installed by default)
- Replacement screws
- Lid
- Power cable
- User guide
- Portion chart

Product Overview

1. Cover
2. Cover Lock
3. Food Compartment
4. Display
5. Cover Release Button
6. Body
7. Food Outlet
8. Food Bowl
9. USB Port
10. Power Button
11. Battery Compartment




Control Panel



Using your New Automatic Feeder


Assemble Unit

1. Attach the bowl to the designated notches underneath the main body.
2. Plug a USB cord into the USB port at the rear of the main body, and attach the other end to a power adapter. If you do not wish to use the power adapter, you may install batteries.



Install Batteries

1. Open the battery compartment at the bottom of the feeder body.
2. Install three alkaline D batteries. Make sure battery wrappings are not torn and that you match the positive and negative poles with the markings in the compartment.
3. Make sure the power switch is in the on position ("I").



Check Motor Functions

1. Press and hold the MANUAL button on the feeder for three (3) seconds. The rotor should rotate and release one portion.
2. Repeat this process two more times. If it completes successfully, then the motor functions are working with no issues.





Set the Time

1. Press and hold the TIMER and HOUR buttons simultaneously until the numbers start flashing.
2. While holding down the TIMER button, press the HOUR button to cycle forward until you reach the correct hour. Please pay attention to AM/PM settings.
3. Repeat the same process for the minutes using the TIMER and MINUTE buttons.



Setting Meals & Meal Sizes

1. Toggle Meals ON/OFF: Press and hold the corresponding MEAL and ON/OFF buttons simultaneously to toggle ON/OFF on the display, indicating whether or not the pet is being fed that specific meal. Meals set to OFF will not be dispensed.
2. Set Portion Amount: Press and hold the corresponding MEAL and AMOUNT buttons simultaneously. Press AMOUNT while holding down MEAL to adjust the portion size from 1-39. Refer to the included portion chart to determine your appropriate portion size.
3. Set Meal Time: Press and hold the corresponding MEAL and HOUR buttons simultaneously. Press HOUR while holding down MEAL to set the hour for that meal to dispense. Repeat this process with the MEAL and MINUTE buttons to set the minutes if needed.



Record a Voice Message

1. Press and hold the REC button for three (3) seconds until the LCD display starts flashing.
2. Record your personalized message.
3. To review your message, press and hold the PLAY button for three (3) seconds. The message will play at each designated meal time.



Manual Dispensing

1. Press and hold the MANUAL button for three (3) seconds to manually dispense one (1) portion of food.
2. Repeat until the desired portion has been dispensed.



Review Settings


1. Press and hold the corresponding MEAL button. The LCD display will show the time and portion size for that meal.



Switching to Small Portion Dispenser


NOTE: Most standard food sizes require the pre-installed large portion dispenser. Only use the small portion dispenser with smaller-sized kibble.

1. Empty and remove the food bucket and flip it upside down.
2. Remove the screws holding the portion dispenser wheel in place.
3. Replace the large portion dispenser with the small portion dispenser.
4. Replace the screws.



Care and Maintenance

1. The feeder bowl is dishwasher-safe for your convenience.
2. The internal food container is not dishwasher-safe, but can be removed and cleaned with water and a mild cleaning agent. Use only pet-safe cleaning agents and make sure to thoroughly rinse and fully dry the food bucket before replacing it.
3. The body of the feeder is not dishwasher-safe. Do not submerge the body in water; this could damage the internal electronics and cause the batteries to short out, create an electrical shock, or catch fire.
4. To clean the body, wipe it with a soft cloth and a mild cleaning agent.
5. If the LOW BATTERY indicator LED starts flashing, replace the batteries in the battery compartment, or connect the feeder to a power adapter. Three (3) alkaline D batteries should last approximately one (1) year, depending on the quantities and frequency of food being dispensed.
6. Make sure all parts of the feeder are completely dry before refilling and re-assembling the device.
7. Exposure to sunlight could damage the internal electronics or cause discoloration; be sure the device is placed in a shady place.



Safety Precautions

1. **WARNING: CHOKING HAZARD – Small parts.** This product contains small parts and is not suitable for children under 3 years old.
2. Remove all packaging before using this device. Please keep all packaging materials out of reach of children and pets.
3. Properly dispose of all packing materials immediately after unpacking product, as the bags used for packaging could present a suffocation or choking hazard.
4. Read all instructions carefully before attempting to operate this device. Improper usage could result in your pet(s) not being fed properly or not being fed at all. Improper use or mishandling could also result in permanent damage to your device.
5. Only use this feeder indoors, in a dry place, and on solid, even ground.
6. Only use dry kibble in this feeder.
7. Always keep fingers, hands, and other appendages clear of the internal food wheel to prevent accidents or injuries.
8. Always turn the unit off before cleaning.
9. Make sure to check the level of food regularly to ensure the feeder is dispensing food properly.
10. This product was not intended for use or play by children, and we recommend you do not allow children to play or tamper with it, to reduce the risk of important settings being changed or damage to the feeder and its moving parts. Adult supervision should always be required when children are near the feeder.
11. Do not try to disassemble the feeder or repair it on your own.
12. Remove all batteries if you are not using the feeder for an extended period of time.
13. Do not mix types and brands of batteries in the feeder. Batteries are not included.

Technical Specifications

- Dimensions: 9.84" W x 13.8" D* x 15.4" H (25 x 35 x 39 cm)
* with food bowl attached
- Weight: 6.61 lbs. (3 kg)**
** without batteries and food
- Capacity: ~20 cups dry food (7L)
- Material: ABS Plastic
- Working Voltage: 5V/1A
- Battery Type: Three (3) Alkaline D Batteries (not included)

Warranty Information

LIMITED WARRANTY ON PAWPLE™ 7L AUTOMATIC PET FEEDER

THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

WE WARRANT THAT DURING THE WARRANTY PERIOD, THE PRODUCT WILL BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP.

LIMITATION OF LIABILITY

TO THE EXTENT NOT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. EXCEPT FOR THE EXPRESS WARRANTIES CONTAINED IN THIS LIMITED WARRANTY STATEMENT AND TO THE EXTENT NOT PROHIBITED BY LAW, WE DISCLAIM ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME STATES DO NOT ALLOW DISCLAIMERS OF IMPLIED WARRANTIES, SO THIS DISCLAIMER MAY NOT APPLY TO YOU. TO THE EXTENT SUCH WARRANTIES CANNOT BE DISCLAIMED UNDER THE LAWS OF YOUR JURISDICTION, WE LIMIT THE DURATION AND REMEDIES OF SUCH WARRANTIES TO THE DURATION OF THIS EXPRESS LIMITED WARRANTY.

OUR RESPONSIBILITY FOR DEFECTIVE GOODS IS LIMITED TO REPAIR, REPLACEMENT OR REFUND AS DESCRIBED BELOW IN THIS WARRANTY STATEMENT.

WHO MAY USE THIS WARRANTY? C&A Marketing, Inc. located at 114 Tived Lane East, Edison, NJ (“we”) extend this limited warranty only to the consumer who originally purchased the product (“you”). It does not extend to any subsequent owner or other transferee of the product.

WHAT DOES THIS WARRANTY COVER? This limited warranty covers defects in materials and workmanship of the Pawple 7L automatic pet feeder (the “product”) for the Warranty Period as defined below.

WHAT DOES THIS WARRANTY NOT COVER? This limited warranty does not cover any damage due to: (a) transportation; (b) storage; (c) improper use; (d) failure to follow the product instructions or to perform any preventive maintenance; (e) modifications; (f) unauthorized repair; (g) normal wear and tear; or (h) external causes such as accidents, abuse, or other actions or events beyond our reasonable control.

WHAT IS THE PERIOD OF COVERAGE? This limited warranty starts on the date of your purchase and lasts for one year (the “Warranty Period”). The Warranty Period is not extended if we repair or replace the product. We may change the availability of this limited warranty at our discretion, but any changes will not be retroactive.

WHAT ARE YOUR REMEDIES UNDER THIS WARRANTY? With respect to any defective product during the Warranty Period, we will, at our sole discretion, either: (a) repair or replace such product (or the defective part) free of charge or (b) refund the purchase price of such product if an exchange unit cannot be provided.

HOW DO YOU OBTAIN WARRANTY SERVICE? To obtain warranty service, you must contact us at 1-833-665-2184 or by email at support@pawplepets.com during the Warranty Period to obtain a Defective Merchandise Authorization (“DMA”) number. No warranty service will be provided without a DMA number and return shipping costs to our facilities shall be assumed by you, the purchaser. Shipping costs of the replacement unit to you shall be assumed by us.

Get in Touch!

support@pawplepets.com

1-833-665-2184

PAWPLE, the PAWPLE logo, PETS ARE PEOPLE, TOO!, and the BAR CODE DEVICES are trademarks of C&A IP Holdings, LLC, in the U.S.

All other products, brand names, company names, and logos are trademarks of their respective owners, used merely to identify their respective products, and are not meant to connote any sponsorship, endorsement or approval.

Distributed by C&A Marketing, Inc., 114 Tived Lane East, Edison, NJ 08837. Made in China.

© 2019. C&A IP Holdings, LLC. All Rights Reserved.