


## Assembly Instructions for Model 130

### IMPORTANT INFORMATION!

1. If you discover any parts are missing, immediately call our toll-free service helpline at 1-800-428-8560.
2. Please save sales receipt as proof of purchase for warranty purposes.
3. You will need a phillips head screwdriver for assembly.



### Parts Identification

**A Playpen** - Wire structure.

**B Plastic Pan** - Plastic tray that fits in the bottom of the cage.

**C Shelf (3)** - Wire structure with plastic sheet insert.


**D Bed** - To be attached to one of the shelves.

**E Caster (4)** - To be attached to playpen with included hardware.




**F Plastic Caster Plate (4)** - Used to attach the casters.

**G Steel Caster Plate (4)** - Used to attach the casters.

**H Nuts & Bolts (16 sets)** - Used to attach the casters.



Note: Illustrations not shown to scale







### Assembly Instructions

Note: Although it can be assembled by one person, due to the size, you may find it easier to assemble with 2 able people.


**1** Lay Cat Playpen on floor. Separate all parts. Remove all wires used to bundle the cage together. Unfold cage by lifting both side and end panels upright one section at a time.

**2** Secure the sides to the ends by lifting the end panels into the corner locks located on the side panels.


**3** When all sides are secure, swing the top panel over and secure all the hooks on the top panel to the top wires of the corresponding sides.



**4** To operate and lock the doors, close the door and lift the handle up and turn it in so it loops around the corresponding wire. Be sure that the top hook (inset A) and bottom hooks (inset B) are secure.




**5** For added security, a Safety Hook is attached to the door that will secure the Latch Handle in place.




**6** With the doors securely latched, tip the assembled playpen on the side to attach the casters. Locate the Casters, Plastic Plates, Steel Plates and the Nuts & Bolts.

**7** The casters will be placed in the four corners of the base at 2 intersecting wires.




**8** Place the Plastic Plate on the bottom of the intersecting wires so the bottom wire fits in the "channel." Put the Steel Plate on the top so the wire fits in the "channel." Put the Caster up against the Plastic Plate so all the holes line up. Insert a bolt in each hole and secure it with a nut.



**9** Carefully set the Playpen upright on the casters. Locate the Shelves and the bed.


**10** Attach the bed to one of the shelves by looping the Velcro strip through the wire in the corner of the shelf and securing it on the under-side of the bed.



- 11** Open the doors and install the shelves by placing the hook on the far side over a wire and then hooking it on the front of the playpen. Be sure that the side of the shelf with the hooks closest to the edge are positioned to the outer side of the Playpen.



- 12** Slide the Plastic Pan in through the opening at the bottom of the playpen. Secure the pan in place with the wire pan stop.



### LIMITED MANUFACTURERS WARRANTY

- For one (1) year for the date of original purchase, MIDWEST Homes For Pets ("MIDWEST") warrants to the purchaser of this pet home that, should it prove defective by reason of improper workmanship and/or material, MIDWEST will repair or replace, at its option, any defective part of the pet home, without charge for the part or for shipping. Replacement parts are warranted for the remainder of the original period.
  - THIS WARRANTY DOES NOT COVER** defects in the wire enclosure caused by any animal, any physical abuse to or misuse of the pet home, any damage caused by the original purchaser or any third party, or any defects arising or discovered more than one (1) year from the original retail purchase date.
  - STEPS TO OBTAIN WARRANTY SERVICE:**
    - The purchaser must call MIDWEST's HELPLINE, 800-428-8560, to report the alleged defect to a customer service representative or obtain missing parts.
    - The customer service representative will determine if the defect is covered by this warranty, and if it is, will authorize and instruct the purchaser in how to obtain corrective action.
    - MIDWEST may require the purchaser to present the sales receipt or other proof of purchase prior to authorizing any return or replacement. No returns or replacements will be permitted without proper authorization. If a return or replacement is authorized, you may be requested to return the item to MIDWEST or to make the item available for pick-up by MIDWEST.
  - ANY EXPRESS WARRANTY NOT PROVIDED IN THIS WARRANTY DOCUMENT, AND ANY REMEDY FOR BREACH OF CONTRACT THAT, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION OR OPERATION OF LAW, IS HEREBY EXCLUDED AND DISCLAIMED. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY LIMITED TO A TERM OF ONE (1) YEAR.**
- SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.**
- UNDER NO CIRCUMSTANCES SHALL MIDWEST BE LIABLE TO PURCHASER OR ANY OTHER PERSON OR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER ARISING OUT OF BREACH OF WARRANTY, BREACH OF CONTRACT OR OTHERWISE, SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATIONS OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSION MAY NOT APPLY TO YOU.**
  - This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

