

CAT MATE® ELECTRONIC I.D. DISC

For use with:

- Cat Mate Microchip Cat Flap (Ref. 360)
- Cat Mate Elite I.D. Disc Cat Flap with Timer Control (Ref. 305)
- Cat Mate Elite I.D. Disc Cat Flap (Ref. 306)
- Cat Mate Elite Microchip Cat Flap with Timer Control (Ref. 355)
- Cat Mate Elite Microchip Cat Flap (Ref. 356)

D Nur zur Verwendung mit:

- Cat Mate Mikrochip Katzenklappe (Ref. 360)
- Cat Mate Elite I.D.-Marke Katzenklappe mit Zeitschaltuhr Funktion (Ref. 305)
- Cat Mate Elite I.D.-Marke Katzenklappe (Ref. 306)
- Cat Mate Elite Mikrochip Katzenklappe mit Zeitschaltuhr Funktion (Ref. 355)
- Cat Mate Elite Mikrochip Katzenklappe (Ref. 356)

F Pour utilisation avec:

- Châtière micropuce Cat Mate (réf. 360)
- Châtière disque d'identification avec fonction de temporisation Cat Mate Elite (réf. 305)
- Châtière disque d'identification Cat Mate Elite (réf. 306)
- Châtière micropuce avec fonction de temporisation Cat Mate Elite (réf. 355)
- Châtière micropuce Cat Mate Elite (réf. 356)

E Para uso con:

- Gatera de Microchip de Cat Mate (Ref. 360)
- Gatera con Disco de I.D. con Control de Tiempo de Cat Mate Elite (Ref. 305)
- Gatera con Disco de Cat Mate Elite (Ref. 306)
- Gatera de Microchip con Control de Tiempo de Cat Mate Elite (Ref. 355)
- Gatera de Microchip de Cat Mate Elite (Ref. 356)

NL Voor gebruik met:

- Cat Mate Microchip Kattendeur (Ref. 360)
- Cat Mate Elite I.D. Disc Kattendeur mit Tijd klok Functionering (Ref. 305)
- Cat Mate Elite I.D. Disc Kattendeur (Ref. 306)
- Cat Mate Elite Microchip Kattendeur mit Tijd klok Functionering (Ref. 355)
- Cat Mate Elite Microchip Kattendeur (Ref. 356)



International Patents Pending. Registered Design.
Designed and manufactured by Pet Mate Ltd. England.
Assembled Worldwide. 31001/1216

Ref. 310



CAT MATE® ELECTRONIC I.D. DISC


ELEKTRONISCHE I.D.-MARKE

DISQUE D'IDENTIFICATION ÉLECTRONIQUE

DISCO DE I.D. ELECTRÓNICA

ELEKTRONISCHE I.D. DISC

Ref. 310



CAT MATE® ELECTRONIC I.D. DISC

D ELEKTRONISCHE I.D.-MARKE

F DISQUE D'IDENTIFICATION
ÉLECTRONIQUE

E DISCO DE I.D. ELECTRÓNICA

NL ELEKTRONISCHE I.D. DISC


The I.D. Disc should be attached to your cat's collar (NOT from a ring attached to the collar) so that it is as high as possible and parallel to your cat flap. We recommend the use of a fabric collar without large metal attachments (other name discs etc.).

Program the new I.D. Disc to your specific Cat Mate product model as follows:

Cat Mate Microchip Cat Flap (Ref. 360)

- Partially remove the battery cover (A, Fig. 1) to reveal the 'PROGRAM' button (B).

Fig. 1



- Press and hold the 'PROGRAM' button for 5 seconds until the LED (C) illuminates. Wait a minimum of 10 seconds.
- Place the front of the I.D. Disc in the tunnel opening.
- When programmed, the LED will flash.
- Press the 'PROGRAM' button to save the setting.




Cat Mate Elite I.D. Disc Cat Flap with Timer Control (Ref. 305) and Microchip Cat Flap with Timer Control (Ref. 355) - current model

If your cat loses its I.D. Disc, you will need to re-program its replacement as follows:

- Press the 'PROG' button (D, Fig. 2) for 5 seconds, the next unused Cat number will flash and there will be lines moving around the first 'TWO ZEROS'.

Fig. 2




- Press the '+' button (E) to select the appropriate Cat number you wish to reprogram.
- Place the front of the I.D. Disc in the tunnel opening.
- When programmed, the 'TWO ZEROS' will disappear and 'Pr' will flash.
- Press the 'PROG' button to save the setting.

Cat Mate Elite I.D. Disc Cat Flap with Timer Control (Ref. 305) and Microchip Cat Flap with Timer Control (Ref. 355) - old model

If your cat loses its I.D. Disc, you will need to re-program its replacement as follows:

- Press the 'PROGRAM' button on the circuit board under the battery cover (F, Fig. 3), for 5 seconds. On the LCD 'CAT 1' and the 'NUMBER 1' will flash - there will be lines moving around 'TWO ZEROS'.

Fig. 3



- Press the '+' button to select the appropriate I.D. Disc number.
- Move the I.D. Disc close to the flap and the rotating 'TWO ZEROS' will disappear.
- Press 'SET' button to save the setting.

